



gruppo bobina		pag. A	
pos.	codice	pos.	codice
1	F20,32,9	6	LE3240B15
2	F650	7	I062
3	LE32NB01	8	CD390
4	LE3240A80	9	TU32/70
5	LE3240B14	10	LE32A600



gruppo telaio inferiore


pag. B

pos.	codice	pos.	codice
1	LE32BB00	11	LE32NB11
2	LE32B5B0	12	LE3240D90
3	PF40/M80	13	LE32NB13
4	LE32NB08	14	C3D14
5	PM080000	15	LE32B004
7	CM080000	16	C6D380000
8	4.00.6000		



12

13




gruppo guidatubo

pag.

C

pos.	codice	pos.	codice
1	CP3X30000	8	LE32C0800
2	LE3240C10	9	MC1/2
3	VB40LE32	10	LE32C6000
4	PF204000	11	CA50/4950
5	LE32C050	12	LE32B300
6	VCE08X010	13	LE32NB13
7	PI133206		




gruppo rientro


pag.

D

pos.	codice	pos.	codice
1	LE40E010	10	1202033
2	LE32E020	11	0502514
3	LE32E030	12	L32PD12C
4	BA034000	13	1262033
5	LE25E030	14	LE40E060
6	LE32ND02	15	LE32E040
7	TUBAC320	16	SAR100
8	PM40/835	17	LE32E070
9	TUBAC32C0		




gruppo rientro		pag. D	
pos.	codice	pos.	codice
1	IN180000	11	LE32E070
2	MV18MF00	12	LE32B300
3	0502514	13	LE32PD03
4	LE32E141	14	VIM100TP
5	GMAD4535	15	SWIFTM100
6	P35.45.7	16	MV14MF00
7	I045	17	1202022
8	L32PD12C	18	L32PD18C
9	1262033	19	LE32E070
10	SAR100		



gruppo carrello

pag. E

pos.	codice	pos.	codice
1	LE32F100		
2	F20,32,9		
3	RA180B12		
4	COP18000		
5	LE32F050		



gruppo irrigatore

pag. F

pos.	codice	pos.	codice
01	30290	17A	30308
01A	30291	18-19	30309
02	30292	20	30311
03	30293	21	30312
04	30294	22	30313
05	20076	23	30314
06	30296	24	30315
07	30297	25	30316
08	30298	26	30317
09	30299	26A	30325
10	30300	27	30319
11	30301	28	30320
11A	30302	28A	30321
12	30303	29	30322
13	30304	30	30323
13A	30305	31	30324
14	30306	32	30325
17	30307		